

# M.C.S.

Roofing and Cladding Supplies Ltd

01538 398 708

[mcsroofing.co.uk](http://mcsroofing.co.uk)

[info@mcsroofing.co.uk](mailto:info@mcsroofing.co.uk)

Brooklands Way, Basford Lane Industrial Estate, Leek ST13 7QF



## Wall Sheets Installation Guide

Observe the general installation sequence:

1. Fit and fix weather sheets.
2. Fix flashings. Use foam filler pieces and butyl sealant to form weather tight junctions.

## Wall Sheets Laying Sequence

The following sequence applies to weather sheets on walls:

1. Set sheet one upright against the framing at the corner of the building with the female edge to the corner. Make sure the profile is vertical.
2. Fix with one fixing in alternate valleys at each rail.
3. Apply a run of 6 x 5mm butyl sealant along the male crown.
4. Set sheet two upright with its female edge lapping the male edge of sheet one.
5. Fix the sheet.
6. Stitch the lap with self-drilling fixings 22mm (weather sheets only) spacing at approx. 450mm centres.
7. Continue to lay sheets along the wall, checking the alignment of the cladding and correcting any deviations.

## Cutting Profiles

Where profiles have to be cut on site:

- Use a powered reciprocating saw or circular saw. Do not use an abrasive wheel.
- Support the profile along the line of the cut.
- Protect the pre-coated finishes of the profile so they do not rust.
- Clean any swarf or debris from the pre-coated finish of the profile immediately.